ANSWERING SYSTEM WALLET CARD

SANYO

CAS-D6320/6322/6323

REMOTE ACCESS AWAY FROM HOME

1. Call your phone number from a touch-tone phone
2. During the outgoing message, press 0 and enter your PIN code. The answering system announces the number of messages stored in memory and the voice prompts.
3. To quit, hang up the phone.

TURN ON THE ANSWERING SYSTEM REMOTELY

1. Call your phone and let it ring 10 times until you hear a beep.
2. Press 0 and then enter your PIN code.
3. Press 0 and then 5 to stop the announcement.
4. Press 0 then 6 to turn the answering system on.

SETTING PERSONAL IDENTIFICATION NUMBER (PIN)

1. On the handset, press **(Menu/Select)**. Select the **ANSW. SETUP** menu, and then the SECURITY CODE submenu.
2. Use the number keypad (**[0]** through **[9]**) to enter a two-digit security code (01-99).
3. Press [Menu/Select]. You will hear a confirmation tone.

TASK	KEY
Repeat a Message	0 oper, 1
Play Incoming Messages	0 oper, 2 abc
Skip a Message	0 oper, 3 def
Delete a Message	0 oper, 4 ghi
Stop Operation	0 oper, 5 jkl
Answering System On	0 oper, 6 mno
Answering System Off	0 oper, 9 wxyz
Help	1, 0 oper

TOLL-FREE help line: 800-263-2244 (Monday-Friday 9-5 Eastern time)